
GAME CONTROL
7
ANALOG CHAN # 1
8
ANTENNA
J2-17
COIN NC
J2-20
COIN NO
J2-18
SYNT NO
J2-19
SYNT NC
J2-21
VSHIFT
J2-2
HSHIFT
J2-3
MODEL
J2-4
-7v
J2-1
J1-8
J1-7
J1-5
J1-11
-12v
+12v
SPKR
TG-9
TG-10
TG-11
TG-12
TG-13
TG-14
TG-15
TG-16
F10
MS
JUMPER TO ACTIVE
JUMPER TO 1 PLYR
JUMPER TO ONE
1 PLYR
ACTIVE
WAN
WRN
TT
D4
D5
C
TA1
TA2
G.O.
RS-6 COIN
128V
128V SW
1 SCAN
2 SCAN
PLYR 1
PLYR 2
NOISE
CRASH 1
CRASH 2
HSYNC
VSYNC
HGATE
VGATE
GREEN
HSHFT 1
VSHFT 1
CRSTP 1
LOSHFT 1
-7v to pin 7 of all LM3900